

The World of Bookbinding.



Refractometer

*Hand refractometer
with temperature compensation*

High-precision instrument to determine the solid contents dissolved in liquids, such as hot glue. A few drops of glue are placed on the refractometer prism and the solids content (index of refraction) may be read off straight away. For cleaning, the cooled glue film is simply pulled off or rinsed off with water.

Technical data:

Measuring area: 45 - 82 %

Scale division: 0.2 %



The hand refractometer fits in every pocket! Delivered in a handy storage case with conversion tables.

