

The World of Bookbinding.



Technical Data Sheet

PräTack Type K11

Applications:

PräTack K11 is a dispersion glue for lamination of untreated paper and cardboard on all common packaging and folding carton machines. The glue is suitable for laminating open and closed wave against cardboard. The glue sets quickly and has a good flatness

Specifications:

Base Material:	PVAc/ Homopolymer dispersion.
Colour:	White.
Solids Content (%):	47 to 2
pH-value:	6 to 8
Viscosity:	4000 ± 400 mPa.s Brookfield at 20 0 C. 4/20
Application temperature:	15 - 25 0 C
Approved:	raw materials comply with FDA "21 CFR 175.105" adhesives.

We recommend not to store this product below 5 0 C as it can be irreversible damaged by frost.

Packing:	Bag-in-Box, 5 and 20 kgs
Storage:	Cool, but not freezing.
Durability:	6 months.

The above description is advisory only and will incur no responsibility for the manufacturer, as the precise actual production environment is outside our control.

The manufacture of this adhesive is based on extensive laboratory experiments and practical experience.

In addition to the above recommendations it is expected that good general work hygiene and all legal requirements be adhered to when using our products.