

The World of Bookbinding.



Technical Data Sheet

PräTack Type E40

Applications:

PräTack E40 is suitable for bonding of bags and corrugated cardboards, book covers in the bindery, treated (PE, PP) surfaces and painted cardboard. The adhesive has a long open time and meets the requirements of faster machine processing. It has been specifically designed for casing-in machines.

Specifications:

Base Material:	PVAc/E Copolymer dispersion
Colour:	White
Solids Content (%):	46 ± 2
PH-value:	4 to 6
Viscosity:	4000 ± 400 mPa.s Brookfield at 20°C. 4/20
Application temperature:	15 - 25°C
Approved:	raw materials comply with FDA "21 CFR 175.105" adhesives.

We recommend not to store this product below 5°C as it can be irreversibly damaged by frost.

Packing:	Bag-in-Box, 5, 10 and 20 kgs
Storage:	Cool, but not freezing.
Durability:	6 months.

The above description is advisory only and will incur no responsibility for the manufacturer, as the precise actual production environment is outside our control. The manufacture of this adhesive is based on extensive laboratory experiments and practical experience.

In addition to the above recommendations it is expected that good general work hygiene and all legal requirements be adhered to when using our products.